

DOMINION OFFROAD

Jeep JK Hi-Lift Jack Mount Kit

Installation instructions

Questions 949-393-1111 www.DominionOffRoad.com

Kit Contents:

(2) Jack Mount Brackets (2) 3/8" Flange Nuts
(1) 3/8" X 1" Hex Flange Machine Screw

We recommend and guarantee fitment with Hi-Lift Brand Jacks only

Required Tools:

- 13mm Wrench - 1/2" Wrench - (2) 19mm (3/4") Sockets or Wrenches

WARNING: Always use a wrenches to tighten fasteners, when mounting your Hi-Lift Jack

1. Apply Logo Stickers as shown in Step 5 picture.
2. Unzip the roll bar cover to gain access to the factory roll bar bracket bolt and back side of seatbelt tube.



3. Identify the seatbelt tube alignment pin on the bracket. (Top right side in previous picture)
4. Remove factory roll bar bracket bolt.
5. Placing the seatbelt tube alignment pin inside the seatbelt tube, install bracket with factory roll bar bolt.



6. Repeat procedure for passenger side bracket:
7. Using the supplied nuts, bolts and washers, install your Hi-Lift Jack as shown:



Posts and write-ups are is greatly appreciated. If you post online, I'd appreciated a link.

